EXPLODED DIAGRAM AND PARTS LIST

6" RANDOM ORBIT SANDER (VACUUM TYPE)
(Model: AT-980-6V)



Part No.	Description	Qty.
1	Main housing	1
2	Screw	1
3	Washer	1
4	Bearing	2
5	Rear plate	1
6	Fixing bolt	3
7	Cylinder	1
8	O-ring	2
9	Rotor	1
10	Rotor blade	5
11	Front plate	1
12	Semi-round key	1
13	Orbit axle	1
14	Fixing screw	1
15	Bearing	2
16	Dust closure	1
17	Spacer	1
18	E-clip	1
19	Bearing stand	1

Part No.	Description	Qty.
20	Gasket	1
21	Head cover	1
22	Dust tube connector	1
23	Screw	1
24	Hex screw	4
25	Dust cover	1
26	Sanding pad	1
27	Spring	1
28	Valve stem	1
29	O-ring	1
30	O-ring	1
31	Valve bushing	1
32	Fixing bolt	1
33	Housing cover	1
34	Trigger	1
35	Fixing bolt	1
36	Air inlet regulator	1
37	Wrench	1